

Model: SPR-127M

User manual










Accessory Package List


No.	Spare part	No.	Spare part	No.	Spare part
A	x1	В	x1	С	×4
No.	Spare part				
D	x1				







ASSEMBLY STEP 3




_Based on the actual usage, press the handle on one side, and adjust the workstation to the proper height



Please do not put hands near the supporting bars, as they change during adjusting and may hurt you.


ASSEMBLY STEP 4








Please make sure all installed equipments are on the table, and not sticking out of the edge, or it may harm or cause damage.



△ WARNING

Hands Pinching







Please do not put hands near the supporting bars, as they change during adjusting and may hurt you.





Please make sure all installed equipments are on the table, and not sticking out of the edge, or it may harm or cause damage.






Please leave enough length of cable for height adjustment function, otherwise it may cause unexpected lost.





Please first adjust it to the highest, then remove equipment to avoid harm or damage.





Attention

Please move it by two persons, or parts may collide and cause damage.

Produced in ChRL for:

DMTrade Mikołaj Tomaszewski Wiśniowa 36; 64-000 Kościan, Poland

NIP: PL 6981681757 sklep@dmtrade.pl

Tel.: +48 661082052 / +48 785082052